

## How to (re) activate your MYLAPS ProChip FLEX transponder

Ready for the new season, or new to the sport? Follow these quick steps to get started within moments.



### Purchase the subscription

1. Go in the web store to the FLEX subscriptions [Link to web shop](#)
2. Select the amount of years you want to add to your subscription (1, 2 or 5 years)
3. Validate your transponder number and enter your personal information
4. The payment can be done with Credit Card
5. Now you must go to the Flex Manager and reactivate your transponder, as per below



### Activate the subscription

1. Download and install the FLEX Manager software (Make sure to select the correct software for your type transponder) [Link to software](#)
2. Connect the transponder to the PC via USB
3. Activate the subscription. Activate your ProChip FLEX Transponder by pressing the 'Activate' button in ProChip FLEX Manager.

**Have a great season!**

